

# Toy Instruction Set Architecture

---

CS 2130: Computer Systems and Organization 1

February 15, 2023


# Announcements

- Homework 3 due next Monday at 11pm on Gradescope

# Encoding Instructions

## Encoding of Instructions

- 3-bit icode (which operation to perform)
  - Numeric mapping from icode to operation
- Which registers to use (2 bits each)
- Reserved bit for future expansion




# High-level Instructions

In general, 3 kinds of instructions

- **moves** - move values around without doing “work”
- **math** - broadly doing “work”
- **jumps** - jump to a new place in the code

# icode 5 and 6

Special property of icode 5-6: only one register used




## Toy ISA 3-bit icode

| icode | b | action         |
|-------|---|----------------|
| 5     | 0 | $rA = \sim rA$ |
|       | 1 | $rA = -rA$     |
|       | 2 | $rA = !rA$     |
|       | 3 | $rA = pc$      |

# icode 5 and 6

Special property of 5-6: only one register used



- Side effect: all bytes between 0 and 127 are valid instructions!
- As long as high-order bit is 0
- No syntax errors, any instruction given is valid



# Immediate values

icode 6 provides literals, **immediate** values

## Toy ISA 3-bit icode

| icode | b | action                                                          |
|-------|---|-----------------------------------------------------------------|
| 6     | 0 | $rA = \text{read from memory at } pc + 1$                       |
|       | 1 | $rA += \text{read from memory at } pc + 1$                      |
|       | 2 | $rA \&= \text{read from memory at } pc + 1$                     |
|       | 3 | $rA = \text{read from memory at the address stored at } pc + 1$ |

For icode 6, increase  $pc$  by 2 at end of instruction



# Encoding Instructions

| icode | b | meaning                                                                                                                |
|-------|---|------------------------------------------------------------------------------------------------------------------------|
| 0     |   | $rA = rB$                                                                                                              |
| 1     |   | $rA += rB$                                                                                                             |
| 2     |   | $rA \&= rB$                                                                                                            |
| 3     |   | $rA =$ read from memory at address $rB$                                                                                |
| 4     |   | write $rA$ to memory at address $rB$                                                                                   |
| 5     | 0 | $rA = \sim rA$                                                                                                         |
|       | 1 | $rA = -rA$                                                                                                             |
|       | 2 | $rA = !rA$                                                                                                             |
|       | 3 | $rA = pc$                                                                                                              |
| 6     | 0 | $rA =$ read from memory at $pc + 1$                                                                                    |
|       | 1 | $rA +=$ read from memory at $pc + 1$                                                                                   |
|       | 2 | $rA \&=$ read from memory at $pc + 1$                                                                                  |
|       | 3 | $rA =$ read from memory at the address stored at $pc + 1$                                                              |
|       |   | For icode 6, increase $pc$ by 2 at end of instruction                                                                  |
| 7     |   | Compare $rA$ as 8-bit 2's-complement to $\theta$<br>if $rA \leq \theta$ set $pc = rB$<br>else increment $pc$ as normal |

Example 1:  $r1 += 19$

# Encoding Instructions

| icode | b | meaning                                                                                                    |
|-------|---|------------------------------------------------------------------------------------------------------------|
| 0     |   | $rA = rB$                                                                                                  |
| 1     |   | $rA += rB$                                                                                                 |
| 2     |   | $rA \&= rB$                                                                                                |
| 3     |   | $rA =$ read from memory at address $rB$                                                                    |
| 4     |   | write $rA$ to memory at address $rB$                                                                       |
| 5     | 0 | $rA = \sim rA$                                                                                             |
|       | 1 | $rA = -rA$                                                                                                 |
|       | 2 | $rA = !rA$                                                                                                 |
|       | 3 | $rA = pc$                                                                                                  |
| 6     | 0 | $rA =$ read from memory at $pc + 1$                                                                        |
|       | 1 | $rA +=$ read from memory at $pc + 1$                                                                       |
|       | 2 | $rA \&=$ read from memory at $pc + 1$                                                                      |
|       | 3 | $rA =$ read from memory at the address stored at $pc + 1$                                                  |
|       |   | For icode 6, increase $pc$ by 2 at end of instruction                                                      |
| 7     |   | Compare $rA$ as 8-bit 2's-complement to 0<br>if $rA \leq 0$ set $pc = rB$<br>else increment $pc$ as normal |

Ex 2:  $M[0x82] += r3$

Read memory at address  $0x82$ , add  $r3$ ,  
write back to memory at same address

# Jumps

- Moves and math are large portion of our code
- We also need **control constructs**
  - Change what we are going to do next
  - **if, while, for**, functions, ...
- Jumps provide mechanism to perform these control constructs
- We jump by assigning a new value to the program counter **PC**

# Jumps

For example, consider an `if`

# Jumps

## Toy ISA 3-bit icode

| icode | meaning                                                                                                                |
|-------|------------------------------------------------------------------------------------------------------------------------|
| 7     | Compare $rA$ as 8-bit 2's-complement to $\theta$<br>if $rA \leq \theta$ set $pc = rB$<br>else increment $pc$ as normal |

Instruction icode 7 provides a **conditional** jump

- Real code will also provide an **unconditional** jump, but a conditional jump is sufficient

# Writing Code

We can now write any\* program!

- When you run code, it is being turned into instructions like ours
- Modern computers use a larger pool of instructions than we have (we will get there)

\*we do have some limitations, since we can only represent 8-bit values and some operations may be tedious.

# Our code to this machine code

How do we turn our control constructs into jump statements?

if/else to jump

while to jump

# Encoding Instructions

| icode | b | meaning                                                                                                    |
|-------|---|------------------------------------------------------------------------------------------------------------|
| 0     |   | $rA = rB$                                                                                                  |
| 1     |   | $rA += rB$                                                                                                 |
| 2     |   | $rA \&= rB$                                                                                                |
| 3     |   | $rA =$ read from memory at address $rB$                                                                    |
| 4     |   | write $rA$ to memory at address $rB$                                                                       |
| 5     | 0 | $rA = \sim rA$                                                                                             |
|       | 1 | $rA = -rA$                                                                                                 |
|       | 2 | $rA = !rA$                                                                                                 |
|       | 3 | $rA = pc$                                                                                                  |
| 6     | 0 | $rA =$ read from memory at $pc + 1$                                                                        |
|       | 1 | $rA +=$ read from memory at $pc + 1$                                                                       |
|       | 2 | $rA \&=$ read from memory at $pc + 1$                                                                      |
|       | 3 | $rA =$ read from memory at the address stored at $pc + 1$                                                  |
|       |   | For icode 6, increase $pc$ by 2 at end of instruction                                                      |
| 7     |   | Compare $rA$ as 8-bit 2's-complement to 0<br>if $rA \leq 0$ set $pc = rB$<br>else increment $pc$ as normal |

Ex 3: `if r0 < 9 jump to 0x42`

# Example

# Example

| icode | b | meaning                                                                                                                |
|-------|---|------------------------------------------------------------------------------------------------------------------------|
| 0     |   | $rA = rB$                                                                                                              |
| 1     |   | $rA += rB$                                                                                                             |
| 2     |   | $rA \&= rB$                                                                                                            |
| 3     |   | $rA =$ read from memory at address $rB$                                                                                |
| 4     |   | write $rA$ to memory at address $rB$                                                                                   |
| 5     | 0 | $rA = \sim rA$                                                                                                         |
|       | 1 | $rA = -rA$                                                                                                             |
|       | 2 | $rA = !rA$                                                                                                             |
|       | 3 | $rA = pc$                                                                                                              |
| 6     | 0 | $rA =$ read from memory at $pc + 1$                                                                                    |
|       | 1 | $rA +=$ read from memory at $pc + 1$                                                                                   |
|       | 2 | $rA \&=$ read from memory at $pc + 1$                                                                                  |
|       | 3 | $rA =$ read from memory at the address stored at $pc + 1$                                                              |
|       |   | For icode 6, increase $pc$ by 2 at end of instruction                                                                  |
| 7     |   | Compare $rA$ as 8-bit 2's-complement to $\theta$<br>if $rA \leq \theta$ set $pc = rB$<br>else increment $pc$ as normal |

# Function Calls

What kinds of things do we put in memory?

- Code: binary code like instructions in our example ISA
  - Intel/AMD compatible: x86\_64
  - Apple Mx and Ax, ARM: ARM
  - And others!
- Variables: we may have more variables that will fit in registers
- Data Structures: organized data, collection of data
  - Arrays, lists, heaps, stacks, queues, ...

# Dealing with Variables and Memory

What if we have many variables? Compute:  $x += y$